
ProLaundry
Best
Practice
Guide





SORTING

- ✓ Keep clean and dirty linen separate
- ✓ Avoid dragging the linen across the floor
- ✓ Always follow the Care Label instructions
- Sort the linen according to wash temperature and divide into coloured, white and dark washing using separate baskets

2.

LOADING/WASHING

- Properly load the machine. Linen should fit comfortably in the drum and not be crammed in for best result.
- Over-loading reduces mechanical action and has many adverse effects on the wash results and the ironing process
- Under-loading increases agitation level, and thereby reduces linen life time; under loading also reduces production efficiency
- ✓ Select correct wash programme and temperature
- Dose the correct amount of detergent according to the dosing instruction. Overdosing does not lead to better wash results
- Add Comfort Deosoft fabric conditioner for increased softness, to help reduce wear and tear and to facilitate ironing

3.

UNLOADING/DRYING

- ✓ Unload clean linen into CLEAN baskets
- If items are still stained after washing they should be re-washed straight away. Tumble drying them 'fixes' the stain and makes it much more difficult to remove in the future
- Always follow the Care Label instructions for tumble drying
- Always remove linen from the dryer once it has stopped. The longer linen stays in the dryer, the more likely it is that creasing will occur
- Do not over-dry items, as this can cause shrinkage, greying and a harsh feel

4.

MACHINE MAINTENANCE

- Regularly clean the detergent and conditioner dosing drawer in the washing machine
- Ensure detergent dosing drawer and washing machine door are left slightly open between wash cycles to help prevent mould build-up
- ✓ Clean the lint filters of the dryer after each cycle



ProTip

